

Product Specification Sheet

PROCHEM®

E400

RED RX

LABEL INSTRUCTIONS

Product Description & Directions for Use:

A special formula designed to remove food and drink colourings and some water-based ink and dye stains from carpets and fabrics. Red Rx is effective on most fruit juice, carbonated drinks, red wine, beverage, and some ink and dye stains.

For professional and industrial use only.

Red Rx must be used as directed and results will depend upon the type, age and size of stain and type of fibre. Most fibres will react safely to Red Rx, but carpet or fabric must always be pretested for colour fastness and texture change in an inconspicuous area, using the application procedure below.

CAUTION - SOME FIBRE DYES AND TWIST PILE CARPETS MAY BE SENSITIVE TO THE HEAT TRANSFER STAIN REMOVAL METHOD. ALWAYS PRETEST BEFORE PROCEEDING WITH APPLICATION.

Apply Red Rx directly to stain only using the nozzle applicator. Avoid contact with surrounding carpet or fabric. For larger stains, Red Rx can be diluted with an equal part of water and applied by trigger sprayer. Blot treated area with white towel or tissue and check for stain colour transfer. Repeat until there is no further improvement.

DO NOT RUB which may cause pile distortion or texture change.

For difficult stains, apply Red Rx to stain only, then dampen a clean white towel with water and place folded damp towel on treated stain. Place a household steam iron, set on high heat, on top of folded damp towel only for 10 to 20 seconds.

Do not allow iron to contact carpet or fabric. Remove iron and inspect towel for stain colour transfer. Repeat process using a clean section of towel until there is no further improvement.



RED RX has been developed exclusively to remove from carpet and fabrics:

- Red food colouring, carbonated drinks, fruit juices, wine stains, some ink and dye stains.
- Effective with wet towel and hot iron method as directed on label.
- Straw liquid with lemon fragrance.

pH: 8.5

DANGER

Causes serious eye damage.

Keep out of reach of children. Do not get in eyes, on skin, or on clothing.

Wear protective gloves / protective clothing / eye protection / face protection.

IF IN EYES: Rinse cautiously with water for several minutes.

Remove contact lenses, if present and easy to do. Continue rinsing.

Immediately call a POISON CENTER / doctor.

Please consult the Safety Data Sheet before using this product.

This product is intended for professional use only. The information given is intended to be of assistance to users but is without guarantee. Variations can occur in application and users are advised to conduct their own tests. Suggestions for use neither give nor imply any guarantee as to the intended use.

Product Name: RED RX **Product Code:** E400

Manufacturer: Prochem Europe Ltd., Oakcroft Road, Chessington, Surrey KT9 1RH, UK.

Telephone No: 020 8974 1515 (UK) +44 20 8974 1515

Website: www.prochem.co.uk Email: sales@prochem.co.uk

Issue Date: 06/11/2014