

# Product Specification Sheet

**PROCHEM®**

**C803 / C812**

**FIBERDRI®**

## LABEL INSTRUCTIONS

### Product Description & Directions for Use:

Fiberdri® is a specially formulated, high quality dry cleaning compound and spill absorbent for carpets and rugs. Fiberdri® contains biodegradable ingredients, a pleasant fragrance and is designed to absorb soil and moisture, allowing carpets to be used immediately after the cleaning procedure. WOOLSAFE Approved maintenance product for wool carpets and rugs.

### For professional and industrial use only.

Before use invert tub for 20 to 30 minutes to allow Fiberdri® to mix properly.

**Carpet and rug general cleaning procedure:** Vacuum carpet thoroughly to remove dry soil and dust. Prespray heavily soiled areas with B107 Prespray Gold. Treat spots with appropriate stain remover. Always pretest carpet for colour fastness with spotting solutions and Fiberdri® before proceeding. Apply Fiberdri® compound by hand or applicator at approx. rate of 1 kilo per 15 square metres, depending upon soiling and pile density. Brush the compound into the carpet with Prochem Fiberdri® machine. Allow compound to activate for 15 to 30 minutes, then vacuum carpet thoroughly to remove all traces of soiled compound. Finally, brush pile to align fibres.

**Spillage absorbent procedure:** Apply Fiberdri® directly to affected area and allow 10 to 15 minutes to activate. Brush or vacuum carpet to remove soiled compound, then brush pile to align fibres. If staining persists, treat with appropriate spot remover and repeat process above.

For best results, keep pack sealed and airtight during storage

**FIBERDRI®** is a dry carpet cleaning compound based upon natural organic compound coated with biodegradable cleaning agents.

- WoolSafe approved for wool carpets and rugs.
- Ready to use in conjunction with brush applicator or Prochem Fiberdri® carpet dry cleaning system.
- Approx. coverage 15m<sup>2</sup> per kilo.
- Golden compound with floral fragrance.

**pH:** 6.0 (as used)

Keep out of reach of children. Do not get in eyes, on skin, or on clothing. Wear protective gloves.

IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Get medical advice / attention.

Contains 2-octyl-2H-isothiazol-3-one. May produce an allergic reaction. Safety data sheet available on request.

Please consult the Safety Data Sheet before using this product.

This product is intended for professional use only. The information given is intended to be of assistance to users but is without guarantee. Variations can occur in application and users are advised to conduct their own tests. Suggestions for use neither give nor imply any guarantee as to the intended use.

**Product Name:** FIBERDRI®

**Product Code:** C803/812

**Manufacturer:** Prochem Europe Ltd., Oakcroft Road, Chessington, Surrey KT9 1RH, UK.

Telephone No: 020 8974 1515 (UK) +44 20 8974 1515

Website: [www.prochem.co.uk](http://www.prochem.co.uk) Email: [sales@prochem.co.uk](mailto:sales@prochem.co.uk)



Issue Date: 21/10/2014